

## SL2600 Digital Radio



## Powering Up the radio

Press and hold down the Power / Lock Keypad Button for one second. Once powered up you will hear a brief tone.


If your radio does not power up, check your battery. Make sure that it is charged and properly attached.

If your radio still does not power up, contact M.R.S. Communications.

## Alarm

The **Alarm** is located on the **the** bottom left hand side of the radio.

### Activating Your Alarm

Press and **HOLD** down the button for 1 second, a brief tone will be heard, the word "STORENET" will appear on the screen along with the following symbol. 

### Receiving Alarm

The radio will transmit a tone to indicate an alarm has been activated and the initiator (of the alarm) name will be displayed on the LCD Screen.

### Resetting Alarm

The Initiator of the Alarm must reset their own radio by pressing the "Alarm Button" again.

The Receiver of the Alarm, must reset their own radio by pressing the "Power Button" once and the OK Button twice.

## SL2600 Digital Radio





Effective town centre radio communication solutions. Providing reassurance to staff and customers in the everyday battle to reduce business crime.

For service, repair or lost radio  
please contact  
M.R.S. Communications  
immediately

M.R.S. Communications Ltd  
Imperial Court  
Viaduct Rd  
Cardiff CF15 9JN  
Tel: 02920 810810  
Fax: 02920 813755

[www.mrscomms.co.uk](http://www.mrscomms.co.uk)



**M-R-S Communications**  
KEEPING YOU TALKING SINCE 1978

**MOTOROLA SL2600**



Thank you for ordering your MOTOROLA SL2600. In order to get the most out of your new handset please take a moment to read these instructions.



INSTRUCTIONS